
SYSTEM BASICS

Home/Sleep/Away System with Touchscreen Keypad




Zone: A point of detection such as a door, window, motion detector, or sensor.


Area: A group of zones. For a Home/Sleep/Away system, these areas are: The perimeter (Home), perimeter plus interior except nighttime areas (Sleep), and perimeter plus all interior areas (Away).

Arm the System

- Tap the shield in the center of the keypad.
- Select an arming type. For Home/Away systems, **SLEEP** is not in the list of options.
 - ► If you're at home: Tap HOME. This arms the perimeter of your house. After arming, the keypad displays HOME SYSTEM ON.
 - If you're at home and staying in nighttime areas: Tap SLEEP. This arms everything except nighttime areas like bedrooms. After arming, the keypad displays SLEEP SYSTEM ON.
 - ► If you're leaving your home and no one will remain inside: Tap AWAY. This arms all areas. After arming, the keypad displays ALL SYSTEM ON.
- If ENTER CODE displays, enter your user code and tap CMD.







Faulted Zones

A zone is *faulted* when it isn't working correctly and the system can't arm it. This could be something like a door being open or a motion detector sensing movement while the system is trying to arm. When a zone is faulted, you have three options: Force it to arm, bypass it, or stop arming so you can fix it.

- ► To force the zone to arm so it becomes part of the protected area when it returns to normal, tap **OKAY**.
- ▶ To bypass the zone so it stays bypassed until the next time the system is armed, tap **BYPASS**. Panic, emergency, fire, flood detector, and temperature sensor zones can't be bypassed.
- ▶ To stop the system from arming so you can fix the problem, tap **STOP**. Fix the problem, then try to arm again.

Disarm the System

During Normal Operation

- 1 Tap the shield in the center of the keypad.
- At ENTER CODE, enter your user code and tap CMD. When the system is disarmed, the keypad displays ALL SYSTEM OFF, then returns to the home screen.





During an Alarm

- Tap the shield in the center of the keypad.
- At ENTER CODE, enter your user code and tap CMD.
- The system displays IS THIS A FALSE ALARM? NO YES.
 - ► For a Real Alarm: Tap NO. This confirms the alarm and notifies the monitoring center that a real alarm is happening. Your security system stays armed.
 - ► For a False Alarm: Tap YES. This cancels the alarm and sends an abort message to the monitoring center. Your security system disarms. The keypad displays ALL SYSTEM OFF, then returns to the home screen.



△✓ 庵			
ABC IS THIS A FALSE			
!@# ALARM?		NO YES	
1 ABC	2 DEF	3 дні	4 JKL
5 ммо	6 PQR	7 sти	8 vwx
9 yz	0	←	CMD